

STEELMATE

Automotive



Make: Suzuki
Model: Carry Van
Year: 2004
Kit Type: Rear

Technical Information



M display can be used in this vehicle and fits on the interior mirror perfectly. The display cable can be run down the near side of vehicle to the rear quarter where the control box will be mounted behind quarter panel trim.

There is absolutely no need to remove bumper and it is very straight forward to get sensor cables into the vehicle.

Sensor measurements are as follows:

A and D sensors are 117cm apart. All sensors are equally spaced at 39cm apart and are all 5cm down from the top of the bumper.

Remove the near side rear light it is held in with two screws, this will reveal an air vent that you can take the sensor cables through into the vehicle.

The wiring loom is in the rear quarter behind the trim. Remove the trim as shown in picture, feed sensor cables through vent and into vehicle. Find the wiring loom from the rear light and split. The reverse wire is red with silver stripes and the ground is black with silver stripes.

After you have made power connections connect up sensors and display to control box, then mount control box with velcro to inner rear quarter as shown in picture.

Remember to do a quick system check before you put the vehicle back together.